

Rack PDU External Ground Connection



Warning: HIGH LEAKAGE CURRENT. EARTH CONNECTION ESSENTIAL BEFORE CONNECTING SUPPLY. If the total leakage current exceeds 3.5 mA, or if the leakage current of the connected loads is unknown, connect the supplementary ground terminal to a reliable ground connection in your facility.

Supplementary ground connection

A supplementary ground terminal is provided on the Power Distribution Unit (PDU) to connect the PDU to a ground connection. The ground terminal has M4 threading and is compatible with all grounding wires.

