



Synergy Global Technology Inc

www.RackmountMart.com

Toll Free: 1-888-865-6888

Tel: 510-226-8368 Fax: 510-226-8968

Email: sales@RackmountMart.com

LCD1U17-36

**17.3" Full HD LED Backlight Dual Rail
Console with Modular KVM Switch
User Manual**

Rev 1.0

Packing List

The complete LCD1U17-36 17.3" Full HD LED backlight dual rail console with modular KVM switch package consists of:

- One 1U 19" rack mount console
- Two rails with front and rear bracket
- Two blockers.
- One 1.8 m KVM cable. (HDDDB-15 / VGA + PS/2 x 2)
- One USB cable
- One DC power adapter
- One power cord
- One user manual CD
- One quick installation guide
- Two keys
- Six flat screws. (for rail mount to console body)
- Two screws. (for combine blockers and console)

Check to make sure that the unit was not damaged in shipping. If you encounter a problem, contact your dealer.

Please read this manual thoroughly, and follow the installation and operation procedures carefully to prevent any damage to the product, and / or any of the devices that connect to it.

Safety Instructions

1. Please read these safety instructions carefully.
2. Please keep this User's Manual for later reference.
3. Please disconnect this equipment from AC outlet before cleaning. Don't use liquid or sprayed detergent for cleaning. Use moisture sheet or clothe for cleaning.
4. For pluggable equipment, the socked-outlet shall be installed near the equipment and shall be easily accessible.
5. Please keep this equipment from humidity.
6. Lay this equipment on a reliable surface when install. A drop or fall could cause injury.
7. Do not leave this equipment in an environment unconditioned, storage temperature above 60 °C, it may damage the equipment.
8. The opening on the enclosure is for air convection hence the equipment from overheating. **DO NOT COVER THE OPENING.**
9. Make sure the voltage of the power source connect the equipment to the power outlet.
10. Please keep the power cord such a way that people can not step on it. Do not place anything over power cord. The power cord must rate for the voltage and current marked on the product's electrical ratings label. The voltage and current rating of the cord should be greater than the voltage and the current rating marked on the product.
11. All cautions and warning on the equipment should be noted.
12. If the equipment is not in use for long time, disconnect the equipment from mains to avoid being damaged by transient over-voltage.
13. Never pour any liquid into ventilation openings; this could cause fire or electrical shock.
14. Never open the equipment. For safety reason, qualified service personnel should only open the equipment.
15. If one of the following situations arises, get the equipment checked by service personnel.
 - The Power Cord or plug is damaged.
 - Liquid has penetrated into the equipment.
 - The equipment has been exposed to moisture.
 - The equipment has not worked well or you can not get it work according to

User's Manual.

- The equipment has dropped and damaged.
- If the equipment has obvious signs or breakage.

Index of Contents

Packing List.....	I
Safety Instructions.....	II
Index of Contents	IV
1. General Information	5
1.1 Feature	5
1.2 Benefits.....	5
1.3 Advantage.....	6
1.4 Product Specification	7
1.4.1 LCD1U17-36 Specification	7
1.4.2 LCD1U17-36 I/O Diagram	8
2. Panel Controls and OSD Function	9
2.1 Input Source	9
2.2 Auto Tune	10
2.3 Brightness.....	10
2.4 Contrast	10
2.5 Color	11
2.6 Position	12
2.7 Language.....	12
2.8 Recall.....	13
2.9 Volume.....	14
2.10 Exit.....	14
3. Installation.....	15
3.1 Install Console into Cabinet	15
3.1.1 Notes	15
3.1.2 Hardware Kits Contents	15
3.1.3 Install Console Step	16
3.2 Install Modular KVM Switch Step.....	17
3.2.1 Hardware Kits Contents	17
3.2.2 Install Modular KVM Switch Step.....	18
3.3 Installing the Video Card and Video Driver.....	19
3.3.1 Configuring the Display Settings	19
3.3.2 Connecting the Console	20
3.4 Fingerprint Scanner	21
3.5 Turning on the Console.....	21
3.6 Testing the Console	21
4. KVM Switch.....	22

1. General Information

LCD1U17-36 Full-HD Patented Dual Rail console offer industrial level input solution to optimize your space utilization by controlling your systems in just 1U. With the unique modular design, you can easily integrate more than 24 models of KVM switches with different functions and expand the connections up to 8 levels of the KVM switches.

1.1 Feature

- Support 1920 x 1080 Full HD resolution
- Provide front USB port to easy data access (optional)
- Support Sun native resolution
- Support 18 various keyboard languages (increasing)
- Bright Active TFT display
- OSD function for LCD display and KVM switch
- Durable keyboard (touchpad, cherry keyboard)
- Sun keys (optional)
- Front USB HUB port (optional)
- Finger Print Scanner (optional)
- With our fully modular IP & CAT5 modules, our customers can create 21 models of KVM Switch from 7 basic models.

1.2 Benefits

1. Feature rich solution: With our unique design and all the options, you can easily suffice the demand for your customer.
2. Time to serve your customer: With the modular KVM, you can easily turn single port console into 8 / 16 / 32 ports console to serve your customer well.
3. Keep low inventory: From the 1 models of consoles and 23 models of KVM switches, you can create total 24 models in this Series. It is the best solution for inventory control.
4. Easy to maintain: Once the defective comes from the KVM switch, you can just swap the KVM switch module without asking your customer to send the whole console back to you.
5. Save freight cost: Since you have to keep only 1 models of consoles and generate new models by yourself, you can ship all the goods by sea instead of

by air. In case, you run out of the KVM switch stock, it is much cheaper to ship the KVM switch modules by air.

1.3 Advantage

Patented Dual Rail design:

The user can leave the LCD flip over , push back the keyboard drawer, and close the cabinet door)

Hidden handle:

After pushing the keyboard drawer back, the handle of the keyboard drawer can also be hidden and offer a flat surface for the cabinet.

Patented extension bracket:

With the patented extension bracket, the console body can extend 13cm. Even there is big server handle or patch panel above the console, our LCD1U17-36 console can have over 90 degrees viewing angle. (compared with 4~5 cm from our competitors and less than 90 degrees in the same condition)

Modular KVM switches:

The user can use LCD1U17-36 console as single port console or through some simple action and few screws to be 8 / 16 even 32 ports KVM consoles.

Various keyboard language support:

To fit the demand of each individual countries.

1.4 Product Specification

1.4.1 LCD1U17-36

Model name	LCD1U17-36
Number of ports	1
Dimension	539.6 x 448.3 x 44 mm / 21.2 x 17.6 x 1.7 inches
Net Weight	13 Kg / 28.7 lbs
Display Size	17.3 inches
Panel Type	Active Matrix TFT LED
Resolution Capabilities	Maximum Resolution up to 1920 x 1080 (Full HD)
Pixel Pitch	Supports 0.264 mm x 0.264 mm
Viewing Angle (CR>10)	Right-Left View 140°(Typ) Up-Down View 120°(Typ)
Contrast Ratio	650 : 1
Brightness	White 300 cd/ m ²
Back Light	Dual Lamps for Back Light
Supported Colors	16.7M Colors (8-bit with FRC)
Response Time	Rising Time 2 ms, Decay Time 6 ms
Operating System	Dos, Unix, Linux, OSX, Windows (XP, 7, 8, Server 2012 R2)
Multi Platform	Support PS/2 and USB
System Cables	VGA + PS/2 x 2 or VGA + USB x 1 cable
Keyboard Mouse	106 key PS/2 keyboard with touch pad
Sync	45 ~ 80 KHz
Power Source	100 ~ 240 VAC input
Power Consumption	10.2W for Panel
Temperature	Operate 0 ~ 50°C / 32 ~ 122°F Storage -20 ~ 60°C / -4 ~ 140°F
Humidity	10% ~ 90% RH
Chassis Construction	Heavy duty steel materials
Keyboard Language	USA, UK, German, French, Spanish, Italian, Portuguese, Dutch, Swiss, Belgium, Swedish, Norwegian, Danish, Japan, Taiwan, Russian, Hebrew, Arabic




Figure 1-2. LCD1U17-36 Dimension

1.4.2 LCD1U17-36 I/O Diagram



Figure 1-3. LCD1U17-36 Front View

- | | |
|-------------------------------|------------------------|
| A. Front USB port1 (optional) | C. Power Display Light |
| B. Front USB port2 (optional) | D. ON/OFF |



Figure 1-4. LCD1U17-36 Rear View

- | | |
|--|----------------------------|
| 1. KVM dock (Only for Combo-free / CAT5 series KVM Switch uses.) | 6. PS/2 mouse |
| 2. USB 2.0 Hub port (optional) | 7. PS/2-USB select |
| 3. DC in | 8. USB Keyboard Mouse Port |
| 4. VGA port | 9. DVI port (optional) |
| 5. PS/2 keyboard | 10. HDMI port (optional) |

2. Panel Controls and OSD Function

Controls	Description
	Soft power on/off button. Adjacent LCD is lit when on.
Auto	Auto-synchronize and scale down display to any valid factory preset timings.
Up▲	Press to scroll the function you want to adjust.
Down▼	Press to scroll the function you want to adjust.
Menu	To access the main menu. This button also acts as the “Enter” button.
Power Indicator	GERRN ON RED STANDBY RED SUSPEND RED OFF

Table 2-1. Panel Controls




Figure 2-1. LCD1U17-36 OSD Control Bar

2.1 Input Source

1. Press the “menu” button.
2. Use the “Down” and “Up” button to scroll.

Input Source

Auto tune
 Brightness
 Contrast
 Color
 Position
 Language
 Recall
 Volume

Exit

3. Press the “menu” button to enter, and you will see:

VGA

DVI

HDMI

AUTOSERCH

4. Use the “Down” and “Up” button to select the input source of signal.

5. Press the “menu” button to enter

2.2 Auto Tune

Press the “auto tune” button. The panel will adjust the display size automatically and also tune the panel to its best condition.

2.3 Brightness

1. Press the “menu” button.

2. Use the “Down” and “Up” button to scroll.

Input Source

Auto tune

Brightness

Contrast

Color

Position

Language

Recall

Volume

Exit

3. Press the “menu” button to enter.

4. Use the “Down” and “Up” button to adjust the brightness of the display.

5. Press the “menu” button to enter.

2.4 Contrast

1. Press the “menu” button.

2. Use the “Down” and “Up” button to scroll.

Input Source

Auto tune
 Brightness
Contrast
 Color
 Position
 Language
 Recall
 Volume
 Exit

3. Press the “menu” button to enter
4. Use the “Down” and “Up” button to adjust the contrast of the display.
5. Press the “menu” button to enter

2.5 Color

1. Press the “menu” button.
2. Use the “Down” and “Up” button to scroll.

Input Source
 Auto tune.
 Brightness
 Contrast
Color
 Position
 Language
 Recall
 Volume
 Exit

3. Press the “menu” button to enter. And you will see:

Icon	Description
9300°K	To set CIE coordinates at 9300°K color
7500°K	To set CIE coordinates at 7500°K color
6500°K	To set CIE coordinates at 6500°K color
User	To set user defined CIE
Auto color	To auto adjust color
Return	To exit and return to the previous page

Table 2-2. Icon Description

4. Use the “Down” and “Up” button to adjust the color of the display.
5. Press “menu” to enter.

2.6 Position

1. Press the “menu” button.
2. Use the “Down” and “Up” button to scroll.

Input Source

Auto tune

Brightness

Contrast

Color

Position

Language

Recall

Volume

Exit

3. Press the “menu” button to enter. And you will see:

Icon	Description
Image Pos	To adjust the position of the image.
OSD Pos	To adjust the position of the OSD.
Return	To exit and return to the previous page

Table 2-3. Icon Description

4. Use the “Down” and “Up” button to scroll.
5. Press the “menu” button to enter.

2.7 Language

1. Press the “menu” button.
2. Use the “Down” and “Up” button to scroll.

Input Source

Auto tune.

Brightness

Contrast
Color
Position
Language
Recall
Volume
Exit

3. Press the “menu” button to enter. And you will see:

English
Deutsch
Francais
Italiano
Espanol

4. Use the “Down” and “Up” button to scroll.

5. Press the “menu” button to enter.

2.8 Recall

1. Press the “menu” button.

2. Use the “Down” and “Up” button to scroll.

Input Source
Auto tune.
Brightness
Contrast
Color
Position
Language
Recall
Volume
Exit

3. Press the “menu” button to enter, and you will see:

Yes/ No

4. Select “Yes” button then ‘Menu’ button to recall the factory setting.

Select “No “ to return to the previous page.

2.9 Volume

For Audio version use.

2.10 Exit

Press the “exit” button to quit OSD menu.

3. Installation


3.1 Install Console into Cabinet

3.1.1 Notes


1. Please check all peripherals according the list before installation. To make sure that the whole unit was not damaged and lost during shipping process. If you encounter any problem, please contact your dealer.
2. Before installation, make sure all peripherals and computer have been turned off.
3. The cabinet depth range must be in 570 ~ 870 mm for 17.3" Full-HD console. Contact your dealer for deeper cabinet application.
4. Reliable grounding of rack-mounted equipment should be maintained. Particular attention should be given to supply connections other than direct connections to the branch circuit.

3.1.2 Hardware Kits Contents

1. Rail with front and rear bracket x 2



2. Blocker x 2




3. Screw x 2



4. Screw (length = 6 mm) x 6




5. Key x 2




3.1.3 Install Console Step

1. Adjust rail with rear bracket to fit your cabinet




2. Install front and rear bracket on cabinet.




3. Repeat step 1~2 for the other side.


4. Push console into rails and reserve 5~10cm space for install the blocker.



5. Install a screw to combine blocker and console. (Both sides)




6. Install three screws (length = 6 mm) in rear of the console (Both sides) to finish the installation.



3.2 Install Modular KVM Switch Step

3.2.1 Hardware Kits Contents

1. Bracket with thumb screw x 2




2. Screw (length = 6 mm) x 4




3.2.2 Install Modular KVM Switch Step

1. Install two screws (length = 6 mm) to combine bracket and KVM switch. (Both sides)




2. Push KVM switch into the rails from rear of cabinet.

plastic rail of KVM switch



3. Tight thumb screw of bracket up to fix KVM switch in console and finish installation. (Both sides)



3.3 Installing the Video Card and Video Driver

Before connecting the LCD console, make sure your computer has a video card already installed for the monitor. After you connect the console, install the video software driver. The video driver is supplied by the video card manufacturer and may be found on the CD-ROM that came with your computer. If you need information on installing a video card or video driver, refer to the manual that came with your video card.

3.3.1 Configuring the Display Settings

After connecting the console and turning on your computer, you may need to configure one or more of the following display settings:

- Display mode (also called desktop area or video resolution)
- Refresh rate (also called vertical scan rate or vertical sync)
- Color depth (also called color palette or number of colors)

Each video card has several controls that let you adjust the display settings. However, the software and driver for each video card is unique. In most cases, you adjust these settings by using a program or utility provided by the manufacturer of the video card. Most video cards use the Windows Display Properties control panel to configure the display. To open the Windows Display Properties, click the right mouse button in a blank area of the Windows desktop and then select **Properties**. The Settings tab usually lets you change the Color Palette and the Desktop Area (*x by y pixel resolution*).

Some video cards integrate additional features into the Windows Display Properties control panel to give you an exceptional setup that is flexible and easy to use. For example, the control panel may include an Advanced Properties button, an Adjustment tab, or a Refresh tab for changing other settings. Other video cards have a separate utility for setting display properties.

Whenever you change the resolution, color, or refresh rate, the image size, position, or shape may change. This behavior is normal. You can readjust the image using the monitor on-screen controls. For more information on the monitor on-screen controls, refer to Chapter 2. For more information on configuring the display settings, refer to the manual that came with your video card.

3.3.2 Connecting the Console

To connect an LCD console to a computer, perform the following steps



Figure 3-1. The rear view of console

1. Turn off your computer. You should always turn off your computer before connecting or disconnecting a device.
2. Connect the video (VGA) connector of the KVM cable to the video card connector on the rear panel of your computer.
3. Identify and connect the PS/2 mouse and PS/2 keyboard connector to the correct PS/2 ports on the rear panel of your computer. Or you can use USB interface to connect your computer. (Use PS/2-USB switch to select your interface. The switch has to be on PS/2 side when you use PS/2 interface connector.)
4. Connect the AC to DC power adapter to the power inlet on the console and then to a power outlet.

With USB Hub :



Figure 3-2. The rear view of console (USB Hub)

1. Turn off your computer. You should always turn off your computer before connecting or disconnecting a device.
2. Connect the video (VGA / DVI / HDMI) connector of the KVM cable (DVI / HDMI) to the video card connector on the rear panel of your computer.
3. Identify and connect the PS/2 mouse and PS/2 keyboard connector to the correct PS/2 ports on the rear panel of your computer. Or you can use USB interface to

- connect your computer. (Use PS/2-USB switch to select your interface. The switch has to be on PS/2 side when you use PS/2 interface connector.)
4. Use USB A-A cable connect USB HUB port and USB port of system.
 5. Connect the AC to DC power adapter to the power inlet on the console and then to a power outlet.

3.4 Fingerprint Scanner

Please install the driver from website or folder “Driver” in CD.




Figure 3-4. Fingerprint Scanner


3.5 Turning on the Console

Make sure all cables and the AC to DC power adapter are connected properly. Be sure to tighten all connector screws. Using two hands, grasp the rear of the console, lift the tab and pull the panel up and forward. This will disengage the momentary on / off switch and the unit should power on. The LCD on the left or under of the monitor panel should turn from orange to green, verifying that the unit is operational.

3.6 Testing the Console

To test that the console is working properly, perform the following steps:

1. Power up the console, and then turn on your computer.
2. Make sure the video image is centered within the screen area. Use the OSD controls to adjust the image (see note below) or press the Auto button on the right hand side of the monitor.



.....
If the unit does not power up when the panel is pulled up, try pushing the soft power on/off button on the left or under side of the monitor panel to power up the unit.
.....



.....
You can adjust the horizontal and vertical position, contrast, and brightness to better suit your video card and your personal preference. Refer to Chapter 2 for more information on using the on-screen menu to adjust the video display.
Before you begin, make sure that powers to all the devices you will be connecting up have been turned off. To prevent damage to your installation due to ground potential difference, make sure that all the devices on the installation are properly grounded. Consult your direct vendor for any technical issues if necessary.
.....

4. KVM Switch

For the KVM switch user manual, please go back to the main menu and select “KVM Switch“.